

# S18 Countertop Flow Meter Instructions Setting Capacity & Timing


## Setting Capacity & Timing

Keep pressing **DISPLAY** button

Then press **RESET** button and  
release both of the buttons.

The DigiFlow 8000T will go into  
setting procedure.

The digit will flash to notice you that  
the setting procedure is on.



## Setting Capacity

Press **DISPLAY** button to choose  
the capacity.

The sequence is:  
0-100-200-300.....9800-9900-OFF-  
0-100.

Then press **RESET** button to save  
the capacity.

Then go into Timing setting.

\*The capacity mode will be disabled  
when you choose OFF.

